



Compulite Systems (2000) Ltd.

Dlite Panel 6.10 and OS 3.4 update instructions.

Preparing the SW update disks:

1. Extract the Dlite Panel 6.10 OS 3.4 update. zip.
3 file will be extracted: Panel_OS_1.exe, Panel_OS_2.exe & Dlite Panel 6.10 and OS 3.4 update instructions.
2. Insert an empty floppy disk into the floppy drive of your PC.
3. Run **Panel_OS_1.exe**, the SW will be written onto the floppy disk.
4. Repeat steps 2 and 3 with **Panel_OS_2.exe**.

Updating the Panel and OS version:

1. Turn power off.
2. Connect a text keyboard and a monitor to the console.
3. Insert **Panel_OS_Disk1** into floppy drive.
4. Press and hold "L" on the external keyboard and turn power on.
5. Observe the messages on the screen, until you see:
"Insert disk # 2"
6. Insert **Panel_OS_2 Disk2** and press any key to continue.
7. Observe the messages on the screen, until you see:
"All files copied successfully"
8. Press any key to continue
9. **Hold down wheels 1 and 3 (left and right wheels) and restart the console:**
10. After the console boots up, you'll see the following messages on the LCD:
**"New panel software found
Loading software from flash
Software size = 40056
Sending software to panel.....
Successful!"**
11. Restart console.
12. Press **'Setup'** and tap **'System Options'**.
13. Verify the following software versions:
 - a. Panel: 6.10
 - b. O/S Image: 3.4

9 Hanagar Street, Neve Ne'eman B Industrial Zone, Hod-Hashron, Israel

www.compulite.com

support@compulite.com