

***Dlite* USB Release Notes**

Release Date	June 25, 2008
Software version	20.0R4
OS version	1.2
Panel version	7.2

ATTENTION! This software is for Dlite USB systems only!



Information in this document is subject to change without notice and does not represent a commitment on the part of Compulite. Compulite assumes no responsibility for any printing errors that may appear in this document. No part of this document may be reproduced or transmitted in any form or by any means, for any purpose other than personal use, without permission from Compulite Systems (2000) Ltd.

Copyright 2006 - 2008 Compulite Systems (2000) Ltd. All rights reserved.

Microsoft is a registered trademark and Windows is a trademark of the Microsoft Corporation.

All other trademarks are properties of their respective holders.

Dlite version 20.0R4 Release notes

June 2008

This document was set up for two sided printing. So conserve trees and print on both sides

Version Highlights - New Features

1.0 Universal Serial Bus

- The floppy disk drive has been replaced by USB. There are two Universal Serial Buses on Dlite's front panel and one on the back panel.
- Support for an external keyboard and mouse on USB.

2.0 Autosave

- Your show is automatically saved every 10 minutes, if **STORE**, **UPDATE**, or **ENTER** has been pressed.
- The autosave file is show 120.
- Use the usual load procedure to load show 120.

3.0 Editing

It is now possible to operate two wheels at the same time. For example, the wheels controlling cyan and magenta.

4.0 Screen resolution

Screen resolution has been upgraded to 1024 x 768

5.0 System capacity upgrade

- Maximum number of channels has been upgraded to 2048.
- Maximum number of devices has been upgrade to 360.
- Maximum number of shows has been upgrade to 360.
- Maximum show file size has been upgraded to 8192 kb.

6.0 Trackball

The trackball sensitivity has been reduced.

Fixed bugs

1. The VC patch was not saved correctly and therefore did not load correctly.
2. the update device message appeared only on the LCD touch screen and not on the external monitor.
3. If you saved a show to the USB stick, disconnected the device, it was impossible to access the files on the flash disk.
4. When a menu or a dialog box was open live view did not refresh.

Limitations

5. The USB stick interferes with Dlite's start up! Work around: Make sure the USB stick is not plugged in before starting up Dlite.
6. An external USB hub requires an external power supply.
7. When loading information to a USB stick, it is required to place shows in a folder named 'Shows' and devices in a folder named 'Devices'. If you do not use these exact folder names, Dlite will not recognize the files.
8. In some cases, the mouse may not function after start up. If this occurs, disconnect and then reconnect the mouse.

Elite

Limitations